Main Mode

leo3 wi

SONY

A1 | A1 II | A7 IV | A7 V | A7R V | A7R VI | A6700

1. Autofocus (exposure reading) in AF-S | AF-A | AF-C and shooting mode change.
To change the shooting mode, press and hold button 1 until the red LED lights up (15 sec.). In MF, it calls up Push Focus.

2. Video or S&Q mode.
Starts or stops video recording. In Photo mode:

Mode 1: Pressing the button activates autofocus; releasing it takes the shot (default setting).
Mode 2: Pressing the button activates autofocus first, then takes the shot. If the objective is already in focus, the shot is taken directly.

3. Video recording (REC).
Starts and stops video recording.

Buttons 4, 5, 6 and 7 change function depending on the camera mode.

Manual Mode	**Shutter Priority (Tv)**	**Aperture Priority (Av)**
4. Aperture -	**4.** EV -	**4.** Aperture -
5. Aperture +	**5.** EV +	**5.** Aperture +
6. Shutter Speed -	**6.** Shutter Speed -	**6.** EV -
7. Shutter Speed +	**7.** Shutter Speed +	**7.** EV +

8. ISO -.
Selects the previous ISO value available from the camera, wrapping at the ends.

9. ISO +.
Selects the next ISO value available from the camera, wrapping at the ends.

Press buttons 4, 5, 6, 7, 8 and 9 once to change the value by one step. Press and hold to change the selected parameter quickly.

10. Switch.
Pressing it changes the keypad functions. In the second mode, the blue LED stays on; in the third mode, it flashes.

11. On/Off.
To turn the electronics on, press until the red LED lights up. TTo turn it off, keep pressing until the LEDs on the base unit switch off. On the A7 V, A7R VI, and A6700 models, the camera monitor will turn off after the time set in the menu, whereas on the A1, A1 II, A7 IV, and A7R V models, the camera monitor will turn off immediately.. The camera will then shut down completely. To reactivate it, switch the electronics back on by pressing this button again.



Front



Leo3 Wi Keypad

Back

Switch Mode

Blue LED On

SONY

A1 | A1 II | A7 IV | A7 V | A7R V | A7R VI | A6700

1. **Center joystick.**
   Confirms the selection.
2. **Shutter / REC.**
   In Photo mode, it takes the shot; in Video and S&Q modes, it starts or stops recording.
3. **Joystick up.**
   Moves the selection up.
4. **Joystick left.**
   Moves the selection left.
5. **Joystick right.**
   Moves the selection right.
6. **Joystick down.**
   Moves the selection down.
7. **Fn.**
   Calls up the camera's Fn function.
8. **Photo / Video / S&Q mode.**
   Cycles through the camera's shooting modes.
9. **Exposure mode.**
   Cycles through M | S | A | P in Photo and Video modes.
10. **Switch.**
    Pressing it changes the keypad functions. In the second mode, the blue LED stays on; in the third mode, it flashes.
11. **On/Off.**
    To turn the electronics on, press until the red LED lights up. To turn off, press until the LEDs on the base turn off.. To reactivate it, switch the electronics back on.

Sony A6700: the joystick is not multidirectional; its directional inputs and center press correspond to the camera's respective buttons.



Front Leo3 Wi Keypad Back

Easydive - Via dell'Industria 13 int 6, 48015 Cervia (RA) - Italy *info@easydive.it - +39 0544 962923 | +39 338 9994219*

Switch Mode

Blue LED Blinking

leo³ wi

SONY

A1 | A1 II | A7 IV | A7 V | A7R V | A7R VI | A6700

1. **Center joystick.**
   Confirms the selection.
2. **Shutter / REC.**
   In Photo mode, it takes the shot; in Video and S&Q modes, it starts or stops recording.
3. **Joystick up.**
   Moves the selection up.
4. **Joystick left.**
   Moves the selection left.
5. **Joystick right.**
   Moves the selection right.
6. **Joystick down.**
   Moves the selection down.
7. **Fn.**
   Calls up the camera's Fn function.
8. **Playback.**
   Opens image playback.
9. **Menu.**
   Opens or closes the camera menu.
10. **Switch.**
    Pressing it changes the keypad functions. In the second mode, the blue LED stays on; in the third mode, it flashes.
11. **On/Off.**
    To turn the electronics on, press until the red LED lights up. TTo turn off, press until the LEDs on the base turn off. To reactivate it, switch the electronics back on.

Sony A6700: the joystick is not multidirectional; its directional inputs and center press correspond to the camera's respective buttons.
Sony A1 and A1 II: in the third mode (blue LED blinking), T7 selects AF Mode instead of Fn.



Front Leo3 Wi Keypad Back

Easydive - Via dell'Industria 13 int 6, 48015 Cervia (RA) - Italy

info@easydive.it - +39 0544 962923 | +39 338 9994219