

## Main Mode

# leo<sup>R</sup>

## Specim IQ

- 1. Pre-Scanner Mode.** Allows you to enable the Pre-Acquisition screen for Focus control and to set the scanning time.
- 2. Start Scanning:** Press once to start the Scanning process.
- 3. Arrow Up.**
- 4. Arrow Left.**
- 5. Arrow Right.**
- 6. Arrow Down.**
- 7. Auto Acquisition.** Pressing this button starts the Auto Acquisition process.
- 8. SET.** Confirms Selection or opens the Camera Menu.
- 9. BACK.** Go back to previous screens.
- 10. Switch Button,** by pressing once you pass to the Switch, and a blue led lights up. Pressing another time turns off the LED and returns to the main mode. Keeping the button pressed for 3 sec. The Housing Menu mode is activated and a purple LED lights up. Follow the numbering of the buttons in this manual to navigate the menus. To exit the menu mode, press button 11 "on / off".
- 11. Housing "on / off" button.** To turn off the housing, press and hold the button until it turns off.



## Switch Mode

Blue Led Activated

- 3. Function USER 1.**
- 4. Function USER 2.**
- 5. Function USER 4.**
- 6. Function USER 3.**
- 7. Function White Ref.** Press to enter the White Balance setting function.

Buttons Panel LeoR